



Installation Guide - i-Flow 50* Generator






INSTALLATION

1.




2.




Unpack the generator from the shipping crate and place on a flat surface.

Ensuring that there is a seal between each fitting and port, Fit the two 12mm Straight fittings to the 'AIR IN' & 'NITROGEN' ports at the rear of the unit. Then fit the 6mm Straight fitting to the port marked 'DRAIN'.

3.



4.




Select the 12mm Tubing and connect to the 'AIR IN' and 'NITROGEN' ports, ensuring the internal olive is crimped securely. It is recommended that PTFE tape is applied to the threads to ensure a leak-tight fit.

Next, select the 6mm Tubing and connect to the '**DRAIN**' port, again ensuring the internal olive is crimped securely.

E: slennon@peakindustrial.com






Fountain Crescent Inchinnan Business Park Inchinnan, PA4 9RE Scotland, UK T: +44 (0)141 812 8100 F: +44 (0)141 812 8200 W: www.peakindustrial.com E: slennon@peakindustrial.com Part No. IG-iFlow50 Rev. 00

Page Page 3 of 5





CONGRATULATIONS

Your **PEAK INDUSTRIAL** gas generator is now fully installed, operational and ready to supply gas on demand to your instrument.

General Notes

< 10 meters: Use 10/8 (10mm O/D, 8mm I/D) Tubing.
> 10 - 40 meters: Use 12/10 (12mm O/D, 10mm I/D). Tubing.
> 40 metres: Please contact Peak Scientific with the relevant distance and we will calculate the flow resistance and the tubing size required.

The imperial equivalents are: 10/8 = 3/8" O/D, 5/16" I/D $12/10 = \frac{1}{2}$ " O/D, 3/8" I/D

For all other technical specifications, operating instructions, service requirements, contact details and trouble shooting, please refer to the user manual contained on the CD supplied in the fittings kit. Please keep this for future reference.

T: +44 (0)141 812 8100

F: +44 (0)141 812 8200

W: www.peakindustrial.com

E: slennon@peakindustrial.com



Part No. IG-iFlow50

00

Page 4 of 5

Rev

Page

28.

It is very important to register your generator with PEAK INDUSTRIAL. This will initiate your warranty entitlement. Please use the form on the next page to register your generator. You will need the generators serial number which can be found on the serial label on the rear of the generator.



IMPORTANT DOCUMENTS

Warranty Entitlement

To register your generator for your warranty entitlement, send the completed form to Peak Scientific by:

- Email <u>warranty@peakscientific.com</u>
- Online http://www.peakscientific.com/service-and-support/warranty-registration
- Phone +44 (0)141 530 4185
- Fax +44 (0)141 812 8200

PRODUCT WARRANTY REGISTRATION	
COMPANY:	CONTACT NAME:
ADDRESS:	
	EMAIL ADDRESS:
CITY/TOWN:	GENERATOR SERIAL NUMBER:
POSTCODE:	
COUNTRY:	MODEL TYPE:
TELEPHONE:	INSTALLATION DATE (DD/MM/YYYY):

Important Please Note:

You have 1 month to register your Peak Scientific product from the date of shipment.

If you wish to defer installation of your generator you must notify Peak Scientific within 1 month of the shipment date. This can be done by emailing warranty@peakscientific.com Once registered the warranty will be honoured for a period of 12 months after the installation date.

For any generators that remain unregistered the warranty will begin from date of shipment.

T: +44 (0)141 812 8100

F: +44 (0)141 812 8200

W: www.peakindustrial.com

E: slennon@peakindustrial.com

Part No. IG-iFlow50

00

Page 5 of 5

Rev

Page

Thank you on behalf of Peak Scientific.